

For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)

Literature Parts



Part No. 4377987

TOP AND CONSOLE PARTS

For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3397618	Literature Parts Instructions, Installation	8	3405156	Switch, Finish Gaurd	23	3406246	Switch, Temperature
	LIT3405635	Guide, Use & Care	9	3390646	Screw, 8-18 x 5/16	24	3398093	Switch, Signal
	LIT3406681	Label, Wiring Diagram	10	349639	Screen, Lint	25	3976570	Timer, 60Hz.
Following May Be Purchased			11		Cover, Lint Screen	26	3394427	Clip, Harness
DO-IT-YOURSELF REPAIR MANUALS				8283378	White	27		Knob, Push-To-Start
	LIT677818	Dryer		8283380	Biscuit		3405992	White
2	3977966	Panel, Control	12	3978605	Hinge, R.H.		3405995	Biscuit
	3977967	White		3978606	Hinge, L.H.	28	3949700	Knob, Control (3)
3	3400859	Screw, Grounding	13	688983	Screw, 8-18 x 5/8		3949704	White
4		End Cap (L.H.)	14	3401144	Connector (Relay/Buzzer)		3949704	Biscuit
	8274353	White	15	688805	Clip	29	3401668	Jumper, Wire
	8274355	Biscuit	16		Top	30	357213	Nut, Push-In (2)
5	237446	Washer		8274386	White	31	3347243	Connector
6	693995	Screw, Hex Head		8274387	Biscuit			6-Circuit
7	8271418	Bracket, Control	17	337686	Screw, 8-18 x 1/2	32	8283276	Wire, Jumper
			18	388326	Screw, Console	33	8274261	Panel, Rear
			19	3395683	Housing, Connector			Console
			20		Knob, Timer	37	3936144	Connector
				3405299	White	42	8299895	Harness, Electric
				3405302	Biscuit	46	3397269	Connector, Timer
			21	3398094	Switch, Push-To-Start	54	297535	Bumper, Lint Lid
					Cap End (R.H.)	62	3390537	Control, Electronic
			22			63	3391885	Connector, Edge
				8274349	White			
				8274351	Biscuit			


OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
ACCESSORY PARTS			PAINT, PRESSURIZED SPRAY (12 oz.)		
	279948	Kit, Dryer Repair		350930	White
PAINT, TOUCH-UP (1/2oz.)				4392901	Biscuit
	72017	White		350938	Primer, Gray
	4392899	Biscuit	PAINT, BULK (1 qt.)		
				799344	White (Uncut)
				4392900	Biscuit (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8	18		Cabinet	35	695737	Door, Rear
2	98669	Locator, Top		8530603	White	36		Door, Front
3	3393008	Screw, 10-16 x 1/2		8530606	Biscuit		3393549	White
5	3396795	Cover, Terminal Block	19	98234	Clip, Ground (2)		3977241	Biscuit
6	342043	Screw, 10-32 x 3/8	20	18776	Lock, Front Top (2)	37		Handle, Door
7	3396805	Panel, Rear	21		Panel, Front		690270	White
8	18849	Pad, Top Hinge		695620	White		3977242	Biscuit
9	692989	Dry Rack Bracket		3977244	Biscuit	38	3406129	Seal & Bearing Assembly
10	3406107	Door Switch Assembly	22	693995	Screw, Hex Washer Head	41	3397659	Block, Terminal
11	697773	Screw, 6-20 x 7/8	23	685203	Clip, Felt Pad (2)	42	3402709	Board, Sound Dampening
12	3394332	Idler & Slide Assembly	24	3389441	Catch, Door	51	238088	Hinge, Top (2)
13	3357011	Screw, 10-16 x 1/2	25	3390731	Seal, Door	56	8066065	Belt, Drive
14	692495	Spring, Door (2)	26	337189	Clip, Hinge (2)	57	348780	Base, Motor
15	3394083	Clip, Front Panel (2)	27	694091	Screw, 8-18 x 3/8	58	3400500	Bolt, 5/16-18 x 3/4
16	3392100	Foot, Plastic Dryer	28	8066056	Hinge, R.H.	59	3394341	Pulley, Motor
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)		8066057	Hinge, L.H.	62	661654	Motor, Drive 60 Hz.
			32	3406839	Dry Rack Assembly	63	660658	Clamp, Motor
			33	696144	Strike, Door	64	3404162	Clamp, Motor (W/Shield)
			34	279393	Terminal Block Kit (For Terminal Block)	66	279318	Terminal, Tinned & Brass (3) (Includes Illus. 34)
						67	343641	Screw, 10-16 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: KEYS850JQ1, KEYS850JT1
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly	15	3404153	Thermostat, 180°F (82.2°C)	42	3399506	Shaft, L.H.
2	489463	Screw, 8-18 x 5/8	16	3398130	Thermostat, 135°F (57.2°C)	43	3399507	Shaft, R.H.
3	8066086	Drum Hole Plug	17	3401338	Heater Element	44	3397588	Roller, Support
4	3388703	Washer-Support	18	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	46	348197	Washer, Support
5	90767	Screw, 8-18 x 3/8	19	3390647	Screw, 8-18 x 1/2	47	3359452	Nut, 3/8-16
6	3390719	Thermal Fuse	20	3394196	Seal, Blower	48	3403414	Bulkhead
7	3387134	Thermostat, Internal-Bias	23	347139	Seal, Lint	62	692526	Ring, Bearing (2)
8	3977393	Thermal Cut-Off (Includes Illus. No. 15)	24	3977373	Bracket, Drum Light	63	97787	Screw, 11-16 x 3/4
9	696302	Shield, Exhaust	25	3403634	Socket Assembly	64	3976434	Bracket, Shaft
10	694089	Wheel, Blower	26	3406124	Light Bulb	65	90296	Clip
11	3405017	Housing, Blower	27	3402841	Lens, Drum Light	66	3406130	Seal, Rear
12	3398161	Clip	28	487909	Screw, 8-15 x 1/2	67	695587	Drum Assembly
13	343641	Screw, 10-16 x 1/2	41	690997	Tri Ring (4)	68	692490	Baffle, Drum (Long) (2)
14	3397566	Box, Heater				69	3403636	Baffle, Drum (Short) (1)
						73	339956	Seal
						81	3976479	Pad, Sensor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST